ZENNOX

Solar Shed Light with Remote-Control and Pull Switch Instruction Manual
G0083

Contents

1 x Lamp unit with 80cm cable
1 x Ceiling mount kit with pull chain switch
1 x Wall bracket
1 x Remote control
1 x Li-ion 3.2V/400mAh rechargeable battery

Installation advice

Before installing the solar panel, it is very important to mount it in the optimum position. The ideal location for the solar panel is outdoors in direct sunlight, where the panel will receive at least 8 hours of direct sunshine. Shady locations will reduce the battery charge and shorten the working time.

Remember during winter months charging time will be reduced due to the number of daylight hours.

Solar panel installation

1. Place the wall bracket on desired location and mark the 2 holes.
2. Drill the two holes, and then insert the wall plugs supplied (not required if fixing to wood).
3. Attach the bracket to wall with screws provided.
4. Fit the solar panel on the bracket.
5. Drill a 12mm hole through the wall large enough to allow you to feed the cable connector through into the shed.
6. Adjust the solar panel to make sure it can receive the most light.

Lamp installation

1. Connect the solar panel cable to the ceiling mount kit cable through the hole previously drilled. Screw the connections together making sure the rubber O ring is tightly in place.
2. Secure ceiling mount kit on the ceiling using the screws and plugs provided within the reach of the cable (3m).

Instructions for use

1. After installation push the switch at the back of the solar panel to OFF position.
2. Leave the solar panel to charge for at least 8 hours with enough sunlight to charge.
3. After this period, push the switch to ON position.
4. Pull out the protection tag of the remote control.
5. Now you can turn the lamp ON or OFF by using the remote control within a 5-metre range or by using the pull chain switch.

Battery replacement

Specification: 1 x 14500, 3.2v 400mAh Li-ion rechargeable battery
If you need to replace the battery at any time, please ensure the replacement is the same specification as the original

1. Switch the power to OFF position.
2. Unscrew the screws of the solar panel.
3. Be careful not to damage the wire while opening the cover
4. Replace the old battery with the equivalent replacement battery.
5. Place the cover back and refit the screws making sure you do not over tighten.
6. Allow 2 days for battery to charge in the OFF position before turning on.

Care and maintenance

Periodically wipe the surfaces of the light and solar panel with a damp clean cloth and then wipe dry. Never immerse in water or use detergents or harsh abrasives as this will damage the light and solar panel.

GUARANTEE
IMPORTANT
Please do not return this product without first calling the Customer Service number below:
0871 911 7031*

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

After Sales Customer Service:
Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP

Telephone: 0871 911 7031*
E-mail customerservice@gardengearonline.co.uk

Please retain for future reference.
 Colours and contents may vary.

  *Calls cost 13p per minute plus your phone company's access charge advice.

Please note that all products with the symbol below must be recycled.