

# **Wooden Cold Frame Instruction Manual**



After Sales Support Call 0871 911 7031 Email customerservice@gardengearonline .co.uk

Product Code: G2164


Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from date of purchase

For correct usage, please read these instructions carefully before first use and store in a safe place for future reference.

### General information and safety warnings


- Keep your plants watered and check on them daily.
- Do not allow children to play in or on the cold frame.
- Do not load on top of the cold frame.
- Assemble on a flat, level surface.
- Never drag the cold frame, always move by carrying equally between two people.
- The cold frame can be secured using simple brackets (not supplied) secured to a solid surface with screws or soft ground with pegs.
- Not suitable for commercial purposes.

### **Parts list**



Make sure that all parts are present before assembly.


## **Assembly**



Make the frame by screwing 2x parts A, B1 and B2 together using screws G.

Make sure that the bevelled edge of Sides A face outwards.

On part B1 ensure the hole is in this position facing outwards. This will be used later.



Attach C to B using G screws.

Make sure that the hinges are attached to the outside of the cold frame.

Screw D to the hinges using 4x H screws.


Finally screw part N on to the side of part D using 1x H

screw.

Use screw M to secure the lid to part B1. Loosen the screw to open and close the lid.

Tighten the screw to hold the lid open in the desired position.

Your cold frame is now ready for use.



#### Care and Maintenance

- To prolong the life of the cold frame, periodically clean the frame and polycarbonate panels with hot soapy water and dry thoroughly.
- The wood has not been pre-treated and would benefit from yearly wood preservative treatment.
- The cold frame is designed to protect young seedlings or cover vegetables and flower beds to extend the growing season.
- Find a sunny yet sheltered location in your garden for your cold frame.
- Check plants in your cold frame daily, keep your plants watered.
- Ventilation is important: even in early spring heat may build up quickly in the cold frame. Remember to open the cold frame to allow ventilation.
- Remember to close the frame during the evening and overnight to protect young and delicate plants from frosts.
- If you feel the need to secure the cold frame to the ground; aftermarket brackets can be purchased from local DIY stores or builders' merchants. Standard 'L-brackets' can be attached to the sides which will then allow you to secure to the ground (by tying, pegging or screwing).

# **GUARANTEE IMPORTANT**

# Please do not return this product without first calling the Customer Service number below:

#### 0871 911 7031\*

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website <a href="www.gardengearonline.co.uk">www.gardengearonline.co.uk</a>. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website. This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

#### After Sales Customer Service:

Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP

Telephone: 0871 911 7031\*

E-mail customerservice@gardengearonline.co.uk

Please retain for future reference.

Colours and contents may vary.

\*Calls cost 13p per minute plus your phone company's access charge