




Four Tier Self-Watering Tomato Tower



For correct usage, please read these instructions carefully before first use and store in a safe place for future reference.

Description of parts



Assembly

Ensure that all parts are present before assembly.

To assemble the planter, simply connect the four sides together and make sure they are secure.




Secure in place on the base of the planter, making sure that each side has clicked securely into position.

Insert the divider base so it lies flat. Add the small water well hood inside by the water access point, this will allow water to fill the well at the base and prevent compost from spilling out of the hole.

Once the planter is assembled, insert the four sticks, one into each corner of the planter.


Secure it with the largest support square, insert four more sticks into the square, and secure with the next largest support square. Repeat this until it's fully assembled.



Fill the planter with compost above the divider base, add your desired plants and add water into the well. Any further watering may be done by simply adding water to the self-watering well, by pouring it through the water access point.



The planter is designed so that your plants can take as much or as little water as they need at any given time. The divider is designed to hold water underneath it and compost on top, it has funnels that sit in the water. The roots then grow down into the funnels and feed from the water when they require.



After initial planting, you will need to water the compost from above to keep roots moist until they have grown long enough to reach the water reservoir below. At this point simply keep the reservoir topped up to keep your tomato plants thriving. Once the first flowers have set, add liquid fertiliser to the water reservoir to encourage the best growth and cropping from your plants.

**GUARANTEE
IMPORTANT**

**Please do not return this product without first calling the Customer Service number below:
0871 911 7031**

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website www.gardengearonline.co.uk. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

After Sales Customer Service:

Customer Service Department, Branded Garden Products Ltd, Premier House,
Hortonwood 7, Telford, TF1 7GP UK

Telephone: 0871 911 7031

E-mail customerservice@gardengearonline.co.uk

Please retain for future reference.

Colours and contents may vary.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Please note that all products with the symbol below must be recycled.



*Calls cost 13p per minute, plus your phone company's access charge