

Rattan Solar Light Instruction Manual



After Sales Support
Call 0871 911 7031
Email
customerservice@gardengearonline.co.uk
Product Code: G4054 G4055

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from date of purchase

For correct usage, please read these instructions carefully before first use and store in a safe place for future reference.

General information and safety warnings

- Keep away from children.
- Do not submerge in water.
- When disposing of batteries, please ensure that they are correctly recycled.
- Do not mix old and new batteries. Mixing old and new batteries could cause leakage of caustic acid that could cause skin burns and damage materials that it contacts.
- When installing batteries, observe the correct polarity.
- Requires 1x AA rechargeable Ni-MH 1.2v 200 mAH battery (included).
- Keep batteries out of reach of children.
- Wear gloves and use caution when removing leaking batteries. Make sure that you dispose of batteries at your local recycling centre.
- This product is for outdoor use only.
- Not suitable for commercial purposes.

Instructions for use

1. Remove all packaging and dispose of correctly.
2. Choose the ideal position in your garden with full, direct sunlight where the solar panel can receive at least 6 hours of sunlight per day.
3. To turn the light on, you must turn the dial (shown below) to the open sign. You can then remove this section and switch the light on inside.



4. The light is controlled by a sensor. At sunset, the light turns on using energy stored in the battery, when you switch it to "off", the solar lamp will preserve energy. If the light does not automatically turn on at sunset check the following:
 - Make sure that the on/off switch is "on"
 - Check the battery for good contact.
 - Make sure that the solar light is place in a well-lit location for maximum sunlight absorption. **Anything that shade the panel will affect the brightness and lighting duration. At least 6 hours of sunlight is required for the lights to illuminate. During winter months, charging time will be reduced due to the limited daylight hours.**

- If the light stops working, you may need to replace the battery. Open the battery cover and replace with a new rechargeable battery.

Cleaning and maintenance

Wipe clean with a soft, damp cloth as and when required to remove surface dust and debris.

GUARANTEE IMPORTANT

Please do not return this product without first calling the Customer Service number below:

0871 911 7031*

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website www.gardengearonline.co.uk. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

After Sales Customer Service:

Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP

Telephone: 0871 911 7031*

E-mail customerservice@gardengearonline.co.uk

Please retain for future reference.

Colours and contents may vary.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

Please note that all products with the symbol below must be recycled.



*Calls cost 13p per minute, plus your phone company's access charge