

# Garden Wall Clock with Humidity and Temperature Metres

## Instruction Manual

G2611 G2612 G2613

### Safety

- Requires 1x AA battery.
- Always observe the correct polarities.
- Dispose of used batteries in accordance with local guidelines.
- Keep out of reach of children and pets.
- Suitable for outdoor use.
- Attach to the wall using suitable wall fixings (not supplied.)

### Please note

When the product is first removed from the packaging, the thermometer and hydrometer will need some time to adjust to their environments. This can take up to 48-72 hours on some occasions.

Hang the clock in an open space to ensure that there is good ventilation around it. This will ensure the sensors are adjusted to be like the surrounding environment.

Do not permanently place the clock near heat or cold sources and do not use the product over the stated measurement ranges on the dials.

### Why the temperature and humidity does not change

The characteristics and principles of the hydrometer means that it will not work correctly indoors. Because air convection is slower and at a more constant temperature, the temperature and humidity dials will change extremely slowly or not at all.

### How to test the thermometer

There will need to be a large difference in the air temperature to test that it is working correctly. You can put the clock into a refrigerator or a warm environment (such as an airing cupboard or warm radiator; but not outside of the range shown on the dials) for 30 minutes then check the difference in temperature showing on the dial.

### How to test the hydrometer

On the back, at the bottom of the hydrometer, there is a row of ventilation holes. Blow a few breaths into the holes a few times and the humidity dial should increase.

**GUARANTEE  
IMPORTANT**

**Please do not return this product without first calling the Customer Service number below:  
0871 911 7031**

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

**After Sales Customer Service:**

Customer Service Department, Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP, UK

Telephone: 0871 911 7031

E-mail [customerservice@gardengearonline.co.uk](mailto:customerservice@gardengearonline.co.uk)

Please retain for future reference.

Colours and contents may vary.

Waste electrical products should not be disposed of with household waste.

Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

**Please note that all products with the symbol below must be recycled.**



\*Calls cost 13p per minute, plus your phone company's access charge