

## Three-Tiered Planter Instruction Manual

G2225

### Assembly

- Before assembling the product, ensure that you have all the correct parts, you should have 3 wheels, 1 base, 2 small planters and 3 large planters.
  - Lay out everything you need on a large, flat and clean area.
1. Insert the castor wheels into the base of the planter.
  2. Slot the three small planters into the base.
  3. Insert the three-plastic water well shelves into the base of each tier.
  4. Then slot on each tier one by one until the planter is fully assembled.



### Instructions for use

The planter is designed so that your plants can take as much or as little water as they need at any given time. The divider in the base is designed to hold water underneath and compost on top, the roots then grow down into the water well and drink what they require.

Fill the water reservoir with cold tap water, do not overfill. Then add your compost on top and plant your flowers or herbs. After initial planting you will need to water the compost from above to keep the roots moist until they have grown long enough to reach the water reservoir below.

If the outside of your planter needs cleaning, simply wipe with a soft damp sponge and allow to dry naturally.

**GUARANTEE  
IMPORTANT**

**Please do not return this product without first calling the Customer Service number below:  
0871 911 7031**

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website [www.gardengearonline.co.uk](http://www.gardengearonline.co.uk). The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

**After Sales Customer Service:**

Customer Service Department, Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP, UK

Telephone: 0871 911 7031

E-mail [customerservice@gardengearonline.co.uk](mailto:customerservice@gardengearonline.co.uk)

Please retain for future reference.  
Colours and contents may vary.

\*Calls cost 13p per minute plus your phone company's access charge